
Instructions:

- Insert all dowels in 8mm holes
- Insert all Cam screws in 5mm holes
- Insert all Cam locks into 15mm holes




- > Attach E and F to B1
- Join B2 to attachment
- > Attach D to B2
- > Join B3 to D
- Attach assembly to C1
- Join C2 on top of assembly and Fasten all Cam Locks
- Use a hammer to knock in the hinges onto the door A
- Use the screws supplied to screw the hinge plates on A onto B1

Novice Plasma Unit

Assembly Instructions

1200mm Wide x 360mm Deep x 430mm high



Important Notes:

- When inserting the CAM, ensure that the triangle arrow is facing the side hole, where the Cam Screw will be inserted.
- Don't fastened the Cam Screw when inserting
- Only fasten it once unit is assembled

Checklist:

PIECE:	SIZE:	
Door	318 x 395	
Side	368 x 330	
Side – Centre	368 x 330	
Side	368 x 330	
Base	1200 x 360	
Тор	1200 x 360	
Fixed Shelf	768 x 300	
Front rail	368 x 80	
Back	368 x 368	
	Door Side Side - Centre Side Base Top Fixed Shelf Front rail	

Fittings:

Wooden Dowels	26		Cam Screws	26	
Cam locks	26	September 1	Straight Hinges	2	
Bun feet plastic	5		Screws for legs 8*40	5	

Tools Needed:



